Dell Precision 5550

Setup and Specifications



Notes, cautions, and warnings

(i) NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2021-2022 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

Chapter 1: Set up your Precision 5550	4
Chapter 2: Chassis overview	6
Left	
Right	
Palmrest view	
Display view	
Bottom view	
DOLLOTT VIEW	
Chapter 3: Specifications of Precision 5550	
Dimensions and weight	
Processors	11
Chipset	11
Operating system	11
Memory	12
Ports and connectors	12
Communications	
Audio	
Storage	14
Media-card reader	14
Keyboard	
Camera	
Touchpad	15
Touchpad gestures	
Power adapter	
Battery	
Display	17
Fingerprint reader	
Video	18
Computer environment	19
Chapter 4: Dell low blue light display	20
Chapter 5: Keyboard shortcuts of Precision 5550	
onapter of negocia oner touts of Freeision cood	
Chapter 6: Getting help and contacting Dell	23

Set up your Precision 5550

About this task

i NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Steps

1. Connect the power adapter to a power source and to either of the USB Type-C port with Power Delivery. Then press the power button on your computer.



- NOTE: You can charge your system by connecting the power adapter to one of the Thunderbolt 3 (USB Type-C) ports that are located on the left side of your computer or to the USB 3.2 Gen 2 (Type-C) port located on the right side of your computer.
- NOTE: The battery may go into power-saving mode during shipment to conserve charge on the battery. Ensure that the power adapter is connected to your computer when it is turned on for the first time.
- 2. Complete the operating system setup.

Table 1. Operating system setup

Operating system	Setup instructions			
	Follow the on-screen instructions to complete the setup:			
Windows	Connect to a network for Windows updates. NOTE: If connecting to a secured wireless network, enter the password for the wireless network access when prompted.			
	If connected to the Internet, sign in with or create a Microsoft account. If not connected to the Internet, create an offline account.			

Table 1. Operating system setup (continued)

Operating system	Setup instructions		
	On the Support and Protection screen, enter your contact details.		
Ubuntu	Follow the on-screen instructions to complete the setup. For more information about installing and configuring Ubuntu, see the knowledge base article https://www.dell.com/support/kbdoc/000131676/how-to-configure-ubuntu-linux-after-it-s-first-installed-on-your-dell-pc at https://www.dell.com/support.		

3. Locate and use Dell apps from the Windows Start menu—Recommended.

Table 2. Locate Dell apps

Resources	Description		
	Dell Product Registration Register your computer with Dell.		
	Dell Help & Support Access help and support for your computer.		
	Dell SupportAssist Pre-boot System Performance Check		
	Dell SupportAssist Preboot System Performance Check is the smart technology that keeps your computer running at its best by optimizing settings, detecting issues, removing viruses and notifies when you must make computer updates. Dell SupportAssist Pre-boot System Performance Check proactively checks the health of your computer hardware and software. When an issue is detected, the necessary computer state information is sent to Dell to begin troubleshooting. Dell SupportAssist Pre-boot System Performance Check is pre-installed on most of the Dell devices running Windows operating system. For more information, see Dell SupportAssist Pre-boot System Performance Check for Home PCs User Guide on https://www.dell.com/serviceabilitytools.		
	NOTE: In Dell SupportAssist Pre-boot System Performance Check, click the warranty expiry date to renew or upgrade your warranty.		
	Dell Update		
Co	Dell Update performs critical fixes and updates latest available device on your computer. For more information about using Dell Update, see the knowledge base article https://www.dell.com/support/kbdoc/en-in/000149088/dell-update-overview-and-common-questions at https://www.dell.com/support/home/.		
	Dell Digital Delivery		
	Download software applications, which are purchased but not pre-installed on your computer. For more information about using Dell Digital Delivery, see the knowledge base article https://www.dell.com/support/kbdoc/000128904/how-do-i-use-dell-digital-delivery at https://www.dell.com/support/home/.		

Chassis overview

Topics:

- Left
- Right
- Palmrest view
- Display view
- Bottom view

Left



- 1. Wedge-shaped security slot
- 2. USB 3.2 Gen 2 Type-C port with Thunderbolt 3 (Power Delivery) (2)

Right



- 1. USB 3.2 Gen 2 Type-C Display port
- 2. SD-card slot
- 3. Universal Audio port

Palmrest view



- 1. Left speaker
- 2. Touchpad
- 3. Left-click area
- 4. Right-click area
- 5. Right speaker
- 6. Power button with fingerprint reader
- 7. Microphones (2)

Display view



- 1. Infrared emitter
- 2. Ambient-light sensor
- 3. RGB-infrared camera
- 4. Camera-status light
- 5. Infrared emitter
- 6. Battery-status light

Bottom view



- 1. Left woofer
- 2. Service Tag label
- 3. Right woofer

Specifications of Precision 5550

Topics:

- Dimensions and weight
- Processors
- Chipset
- Operating system
- Memory
- Ports and connectors
- Communications
- Audio
- Storage
- Media-card reader
- Keyboard
- Camera
- Touchpad
- Power adapter
- Battery
- Display
- Fingerprint reader
- Video
- Computer environment

Dimensions and weight

Table 3. Dimensions and weight

Description		Values	
Height:			
Front		7.70 mm (0.30 in.)	
	Rear	11.65 mm (0.45 in.)	
٧	Vidth	344.40 mm (13.56 in.)	
С	Pepth	230.30 mm (9.07 in.)	
Weight (maximum)		4.51 lb (2.05 Kg) (i) NOTE: The weight of your computer depends on the configuration ordered and the manufacturing variability.	

Processors

Table 4. Processors

Descripti on	Values					
Processors	10 th Generation Intel Core i5-10400H	10 th Generation Intel Core i7-10750H	10 th Generation Intel Core i7-10850H	10 th Generation Intel Core i7-10875H	10 th Generation Intel Core i9-10885H	10 th Generation Intel Xeon W-10855M
Wattage	45 W	45 W				
Core count	4	6	6	8	8	6
Thread count	8	12	12	16	16	12
Speed	2.60 GHz to 4.60 GHz	2.60 GHz to 5.0 GHz	2.70 GHz to 5.1 GHz	2.30 GHz to 5.10 GHz	2.40 GHz to 5.30 GHz	2.40 GHz to 5.30 GHz
Cache	8 MB	12 MB	12 MB	16 MB	16 MB	12 MB
Integrated graphics	Intel UHD 630 Graphics	Intel UHD 630 Graphics	Intel UHD 630 Graphics	Intel UHD 630 Graphics	Intel UHD P630 Graphics	Intel UHD P630 Graphics

Chipset

The following table lists the details of the chipset supported by your Latitude 5320.

Table 5. Chipset

Description	Values
Chipset	WM490
Processor	10 th Generation Intel Core i5/i7/i9 and Xeon W
DRAM bus width	64-bit
Flash EPROM	32 MB
PCIe bus	Up to Gen 3.0

Operating system

Your Precision 5550 supports the following operating systems:

- Windows 10 Home (64-bit)
- Windows 10 Professional (64-bit)
- Windows 10 Pro for Workstations
- Windows 10 Pro Education
- Windows 10 IoT Enterprise (64-bit)
- Ubuntu 18.04 SP1
- Red Hat® Enterprise Linux® 8.2 (Certification Only)

Memory

The following table lists the memory specifications of your Precision 5550:

Table 6. Memory specifications

Description	Values	
Slots	Two-SODIMM slots	
Туре	Dual-channel DDR4, ECC	
Speed	2666 MHz, 3200 MHz	
Maximum memory	64 GB	
Minimum memory	8 GB	
Memory size per slot	8 GB, 16 GB, 32 GB	
Configurations supported	 8 GB, 1 x 8 GB, DDR4, 3200 MHz, dual-channel 16 GB, 2 x 8 GB, DDR4, 3200 MHz, dual-channel 32 GB, 2 x16 GB, DDR4, 3200 MHz, dual-channel 64 GB, 2 x 32 GB, DDR4, 3200 MHz, dual-channel 8 GB, 1 x 8 GB, DDR4, ECC, 2666 MHz, dual-channel 16 GB, 2 x 8 GB, DDR4, ECC, 2666 MHz, dual-channel 32 GB, 2 x 16 GB, DDR4, ECC, 2666 MHz, dual-channel 	

Ports and connectors

Table 7. External ports and connectors

External:	
USB	 Two USB 3.2 Gen 2 Type-C port with Thunderbolt 3 (Power Delivery) One USB 3.2 Gen 2 Type-C Display port
Audio	One Universal Audio port
Video	USB Type-C to DisplayPort adapter (sold separately)
Media card reader	One SD 3.0/4.0/6.0 card
Docking port	Not supported
Power adapter port	USB Type-C port (i) NOTE: Connect the power adaptor (USB Type-C) to only one of the three USB Type-C ports.
Security	One wedge-shaped security slot

Table 8. Internal ports and connectors

Internal:	
M.2	Two M.2 2230/2280 slot for solid-state drives

Table 8. Internal ports and connectors

Internal:		
	i) NOTE: To learn more about the features of different types of M.2 cards, see the knowledge base article 000144170.	

Communications

Wireless module

Table 9. Wireless module specifications

Description	Values
Model number	Intel Wi-Fi 6 AX201
Transfer rate	Up to 2400 Mbps
Frequency bands supported	2.4 GHz/5 GHz
Wireless standards	 Wi-Fi 802.11a/b/g Wi-Fi 4 (WiFi 802.11n) Wi-Fi 5 (WiFi 802.11ac) Wi-Fi 6 (WiFi 802.11ax)
Encryption	64-bit/128-bit WEP AES-CCMP TKIP
Bluetooth	Bluetooth 5.1

Audio

Table 10. Audio specifications

Description		Values	
Controller		Realtek ALC3281-CG	
Stereo conversion		Supported	
Internal interface		High definition audio interface	
External interface		Universal Audio Jack	
Speakers		2-way speaker	
Internal speaker amplifier		Supported	
External volume controls		Keyboard shortcut controls	
Speaker output:			
	Average	4 W	
	Peak	5 W	
Subwoofer output		Supported	

Table 10. Audio specifications (continued)

Description	Values
Microphone	Digital-array microphones

Storage

Your computer supports the following configurations:

- Two M.2 2280 or M.2 2230 solid-state drive
- Supports RAID 0 and RAID 1

The primary drive of your computer varies with the storage configuration. For computers:

• With 2 M.2 drives SSD1 is the primary drive

Table 11. Storage specifications

Storage type	Interface type	Capacity
Up to two M.2 2230 or 2280 solid-state drive	PCle Gen3.0x4 NVMe, up to 32 Gbps	Up to 2 TB

Media-card reader

Table 12. Media-card reader specifications

Description	Values
Туре	One SD 3.0/4.0/6.0 card slot
Cards supported	 Secure Digital (SD) Secure Digital High Capacity (SDHC) Secure Digital eXtended Capacity (SDXC)

Keyboard

The following table lists the keyboard specifications of your Precision 5550.

Table 13. Keyboard specifications

Description	Values
Keyboard type	Backlit keyboard
Keyboard layout	QWERTY
Number of keys	United States and Canada: 79 keysUnited Kingdom: 80 keysJapan: 83 keys
Keyboard size	X=19.05 mm key pitch Y=18.05 mm key pitch
Keyboard shortcuts	Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.

Table 13. Keyboard specifications (continued)

Description	Values
	NOTE: You can define the primary behavior of the function keys (F1–F12) changing Function Key Behavior in BIOS setup program. Keyboard shortcuts

Camera

Table 14. Camera specifications

Desc	Description		Values
Num	Number of cameras		One
Туре)		RGB HD camera/Infrared camera
Loca	tion		Front camera
Sens	or type		CMOS sensor technology
Resc	lution		
	Camer	a	
		Still image	0.92 megapixel
		Video	1280 x 720 (HD) at 30 fps
	Infrared camera		
		Still image	0.2 megapixel
		Video	576 x 360 at 15 fps
Diag	Diagonal viewing angle		
	Camera		78.5 degrees
	Infrared camera		78.5 degrees

Touchpad

Move your finger on the touchpad to move the mouse pointer. Tap to left-click and two fingers tap to right-click.

- NOTE: The top and the sides of the touchpad—8.20 mm (0.32 in.) from the edges—are disabled. This prevents unintended movements of the mouse pointer when using the keyboard.
- (i) NOTE: The touchpad area of the computer is large and your palms may inadvertently touch the touchpad corners when the touchpad is in use. To prevent this, the physical button and the corners of the touchpad (1 cm x 1 cm or 0.39 in. x 0.39 in.) will be ignored and disabled if other touches are detected outside of these corners.

Table 15. Touchpad specifications

Description		Values
Resolution:		
	Horizontal	4655

Table 15. Touchpad specifications (continued)

Description		Values
	Vertical	2731
Dimensions:		
	Horizontal	150 mm
	Vertical	90 mm

Touchpad gestures

For more information about touchpad gestures for Windows, see the Microsoft knowledge base article 4027871 at support.microsoft.com.

Power adapter

Table 16. Power adapter specifications

Description	V	Values	
Туре	90 W USB-C (UMA)	130 W USB-C (Discrete)	
Diameter	Type-C connector	Type-C connector	
Input voltage	100 VAC-240 VAC	100 VAC-240 VAC	
Input frequency	50 Hz-60 Hz	50 Hz-60 Hz	
Input current (maximum)	1.5 A	1.8 A	
Output current (continuous)	 20 V/4.5 A (Continuous) 15 V/3 A (Continuous) 9.0 V/3 A (Continuous) 5.0 V/3 A (Continuous) 	20 V/6.5 A (Continuous)5.0 V/1 A (Continuous)	
Rated output voltage	20 VDC/15 VDC/9 VDC/5 VDC	20 VDC/5 VDC	
Temperature range:	·		
Operating	0 °C to 40 °C (32 °F to 104 °F)	0 °C to 40 °C (32 °F to 104 °F)	
Storage	-40 °C to 70 °C (-40 °F to 158 °F)	-40 °C to 70 °C (-40 °F to 158 °F)	

Battery

Table 17. Battery specifications

Description		Values	
Туре		3-cell lithium-ion 56 WHr	6-cell lithium-ion 86 WHr
Voltage		11.4 VDC	11.4 VDC
Weight (maximum)		0.255 kg	0.340 kg
Dimensions:			
	Height	7.56 mm	7.56 mm
	Width	77.7 mm	77.7 mm

Table 17. Battery specifications (continued)

Description		Values		
	Depth	295.2 mm	295.2 mm	
Temperati	ure range:			
	Operating	Charge: 0 °C to 45 °C (32 °F to 113 °F) Discharge:0 °C to 60 °C (32 °F to 149	Charge: 0 °C to 45 °C (32 °F to 113 °F) Discharge:0 °C to 60 °C (32 °F to 149 °F)	
	Storage	-20 °C to 60 °C (4 °F to 149 °F)	-20 °C to 60 °C (4 °F to 149 °F)	
Operating time		Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.	Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.	
Charging time (approximate)		2 hr (Express charge), 3 hr (Standard charge) (when the computer is off) (i) NOTE: Control the charging time, duration, start and end time, and so on using the Dell Power Manager application. For more information on the Dell Power Manager see www.dell.com/	2 hr (Express charge), 3 hr (Standard charge) (when the computer is off) (i) NOTE: Control the charging time, duration, start and end time, and so on using the Dell Power Manager application. For more information on the Dell Power Manager see www.dell.com/	
Coin-cell battery		Not supported	Not supported	
Operating time		Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.	Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.	

Display

Table 18. Display specifications

Description		Values		
Туре		Full High Definition (FHD+), Non-touch	Ultra High Definition (UHD+), touch	
Panel technology		Wide Viewing Angle (WVA)	Wide Viewing Angle (WVA)	
Luminance (typical)		500 Nits	500 Nits	
Dimensions (A	Active area):			
F	Height	336.38 mm	336.38 mm	
V	Vidth	210.24 mm	210.24 mm	
С	Diagonal 15.6" 15.6"		15.6"	
Native resolution		1920 x 1200	3840 x 2400	
Megapixels		2.3 megapixels	9.2 megapixels	
Color gamut		sRGB 100% min	Adobe 100% min; DCI-P3 94% typical, 90% minimum	

Table 18. Display specifications (continued)

Description	Values	
Pixels per inch (PPI)	145	290
Contrast ratio (min)	1650:1	1600:1
Response time (max)	35 ms	35 ms
Refresh rate	60 Hz	60 Hz
Horizontal view angle	85 +/- degrees	85 +/- degrees
Vertical view angle	85 +/- degrees	85 +/- degrees
Pixel pitch	0.1752 mm	0.0876 mm
Power consumption (maximum)	4.41 W	10.4 W
Anti-glare vs glossy finish	Anti-Glare	Anti-Reflection
Touch options	No	Yes

Fingerprint reader

Table 19. Fingerprint reader specifications

Description	Values
Sensor technology	Capacitive
Sensor resolution	500 dpi
Sensor area	5.49 mm x 4.47 mm
Sensor pixel size	108 x 88

Video

Table 20. Discrete graphics specifications

Discrete graphics			
Controller	External display support	Memory size	Memory Type
NVIDIA Quadro T1000	N/A	4 GB	GDDR6
NVIDIA Quadro T2000	N/A	4 GB	GDDR6

Table 21. Integrated graphics specifications

Integrated graphics			
Controller	External display support	Memory size	Processor
Intel UHD Graphics 630	Type-C	Shared system memory	10th Generation Intel Core i5/i7/i9
Intel UHD Graphics P630	Type-C	Shared system memory	Intel Xeon

Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

Table 22. Computer environment

Description	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing) 0% to 95% (non-condensing)	
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G†	160 G†
Altitude (maximum)	-15.2 m to 3048 m (4.64 ft to 5518.4 ft)	-15.2 m to 10668 m (4.64 ft to 19234.4 ft)

 $[\]ensuremath{^{*}}$ Measured using a random vibration spectrum that simulates user environment.

[†] Measured using a 2 ms half-sine pulse when the hard drive is in use.

Dell low blue light display

WARNING: Prolonged exposure to blue light from the display may lead to long-term effects such as eye strain, eye fatigue, or damage to the eyes.

The ComfortView feature on Dell laptops and displays is designed to minimize blue light emitted from the display for better eye comfort.

To reduce the risk of eye strain after looking at the laptop's display for an extended period of time, it is recommended that you:

- 1. Set the laptop's display at a comfortable viewing distance between 20 inches and 28 inches (50 cm and 70 cm) from your eyes.
- 2. Blink frequently to moisten your eyes, or wet your eyes with water.
- **3.** Take a break for 20 minutes every two hours.
- 4. Look away from your display, and gaze at a distant object at 20 ft (609.60 cm) away for at least 20 seconds during each break

Keyboard shortcuts of Precision 5550

NOTE: Keyboard characters may differ depending on the keyboard language configuration. Keys used for shortcuts remain the same across all language configurations.

Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. The symbol shown on the lower part of the key refers to the character that is typed out when the key is pressed. If you press shift and the key, the symbol shown on the upper part of the key is typed out. For example, if you press **2**, **2** is typed out; if you press **Shift** + **2**, **@** is typed out.

The keys **F1-F12** at the top row of the keyboard are function keys for multi-media control, as indicated by the icon at the bottom of the key. Press the function key to invoke the task represented by the icon. For example, pressing **F1** mutes the audio (refer to the table below).

However, if the function keys **F1-F12** are needed for specific software applications, multi-media functionality can be disabled by pressing $\mathbf{Fn} + \mathbf{esc}$. Subsequently, multimedia control can be invoked by pressing \mathbf{Fn} and the respective function key. For example, mute audio by pressing $\mathbf{Fn} + \mathbf{F1}$.

NOTE: You can also define the primary behavior of the function keys (F1-F12) by changing Function Key Behavior in BIOS setup program.

Table 23. List of keyboard shortcuts

Function key	Redefined key (for multimedia control)	Behavior
Ľ√× F1	fn + □□× F1	Mute audio
	fn + \(\(\sqrt{\frac{1}{5}} \)	Decrease volume
(1)) F3	fn + <a>¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬¬	Increase volume
⊳II _{F4}	fn + ▷II _{F4}	Play/Pause
F5	fn + 运 _{F5}	Toggle keyboard backlight
- ; ¢;-	fn + ∴;	Decrease brightness
F7	fn + : F7	Increase brightness

Table 23. List of keyboard shortcuts (continued)

Function key	Redefined key (for multimedia control)	Behavior
F8 F8	fn + 🗐 F8	Switch to external display
prt sc F10	fn + prt sc	Print screen
home F11	fn + home	Home
end F12	fn + end F12	End

The **Fn** key is also used with selected keys on the keyboard to invoke other secondary functions.

Table 24. List of keyboard shortcuts

Function key	Behavior
fn + B	Pause/Break
fn + S	Toggle scroll lock
fn + R	System request
fn + ctrl	Open application menu
fn + esc	Toggle Fn-key lock

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 25. Self-help resources

Self-help resources	Resource location
Information about Dell products and services	www.dell.com
My Dell	Dell
Tips	*
Contact Support	In Windows search, type Contact Support, and press Enter.
Online help for operating system	www.dell.com/support/windows
	www.dell.com/support/linux
Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.	www.dell.com/support
Dell knowledge base articles for a variety of computer concerns.	 Go to https://www.dell.com/support/home/? app=knowledgebase. Type the subject or keyword in the Search box. Click Search to retrieve the related articles.
Learn and know the following information about your product: Product specifications Operating system Setting up and using your product Data backup Troubleshooting and diagnostics Factory and system restore BIOS information	See Me and My Dell at www.dell.com/support/manuals. To locate the Me and My Dell relevant to your product, identify your product through one of the following: Select Detect Product. Locate your product through the drop-down menu under View Products. Enter the Service Tag number or Product ID in the search bar.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.

- NOTE: Availability varies by country and product, and some services may not be available in your country.
- NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.